

Instructions for 10K Weatherproof Temperature Probe (FGD-0102)

Probe comes with 12 feet of 24 gauge wire and mounting hardware.

Instructions for Express II, 2000 and SCADA 3000

1. Remove any existing wires or sensors from the input terminal.
2. Place the corresponding input shunt in the “a” position for Express II, or the “TMP/DRY” position for the 2000 and SCADA 3000.
3. Program the input type for a 10K thermistor in either Fahrenheit or Celsius.

Instructions for 1400, 1800, 2800, WEB600 and CELL682

The probe may be connected to any available input/zone terminal. Refer to your user’s manual for configuration and programming. To connect the probe:

1. Remove any existing wiring or sensors from the input terminal.
2. Attach wires from the weatherproof temperature probe to the input terminal and ground terminal respectively.

Warning: Do not submerge.

© 2007 Sensaphone 901 Tryens Road, Aston, PA 19014

For Technical Support call 877-373-2700 or E-mail support@sensaphone.com

10K

Weatherproof Temperature Probe