



Sensaphone 4-20 Input Settings:
 Units: **C**
 Table High: **35**
 Table Low: **-200**

(+)  Loop Supply: 8-32VDC
 (-) 

<p>Sensaphone 901 Tryens Rd. Aston, PA 19014 610-558-2700</p>				Title			
				<p>Sensaphone FGD-0240</p>			
Description							
<p>Connection Diagram for Sensaphone Input</p>							
ECN	PN	Rev	Scale				
N/A	N/A	A	N/A				
Date	Drawn	Sheet					
08/06/2015	TJK	1 of 1					